URBANWORX

AIR PRESSURE EYE MASSAGER

UXEM-3

INSTRUCTION MANUAL

General Safety

Read this manual thoroughly before you start using the product.
Store this manual, the completed warranty card, your receipt and the product packaging.
The safety precautions instructions reduces the risk of fire,
Please read the instruction manual carefully in advance to ensure proper operation, especially the cautions, Please keep properly the operation instruction for later review,

CAUTION:

To ensure that you see the massager correctly, please be sure to consult before using and read the use of precautions:

1, Do not use the eye massager while walking or driving outdoors,
2, Do not use eye massager in hot and humid place,
3, Eye symptoms can not be used, had the implementation of eyesurgery, glaucoma, cataract, retinal detachment and other major eye patients banned use,
4, Depth of stroke, hypertensive and hypotensive patients with caution, please consult a professional doctor Division, the use of any discomfort, please stop using it immediately,
5, Mental and physical discomfort or mental retardation caution people, please use it under the supervision of accompanying, if it happens any discomfort during use, please stop using it immediately,
6, Avoid using the eye massager when drinking or feeling unwell,
7, The massager has a hot compress function, the temperature insensitive people will be used to be careful,
8, Please wear the massage device in the eye and then boot, so as not to damage the balloon overpressure,
9, Before wearing, remove contact lenses, hair clips, hair accessories, etc,
10, The massager for personal health products, can not replace drugs or medical equipment,
11, If you feeling hurt in use or serious discomfort, please stop using it and consult Physician,
12, The massager designed for home electronic health products, dose not apply to the diagnosis, treatment and other commercial uses,
13, For cleaning, it should be used with medical alcohol cotton to wipe, can not use water to clean the product, do not put it in the liquid and soak it,
14, Do not disassemble this product by yourself
15, Please use the company's configuration of the power, and pay attention to electricity safety,
16, Please close the eyes when using this product, after using, at start the eyes will be more fuzzy, closing eyes after 1-3 minutes, Your eyes will clear slowly,
17, This appliance is not to be used by persons including children with reduced physical, sensory or mental capabilities, or lack of of experience and knowledge, unless they have been given supervision or instruction, Children being supervised not to play with the appliance,
18, It must only be supplied at SELV,.
19, This appliance containing batteries that are non-replaceble, when the battery is at end of life the appliance shall be properly disposed of,

Product Overview

Main part

USB cable

instruction manual
(Including warranty card)

Operation Instructions

Preparation for use

► please check if there is a need to charge the product. If the function of product cannot be used or the product cannot even boot when battery capacity is low, please use it after recharging. After full charging, please unplug power adapter, not too long time to charge to prolong the life of the product.

Charge

1.Plug the power adapter into the USB outlet.
2.The indicator light is red during charging, and it will be in blue once the battery has been charged completely.
3.The product cannot be used during charging. (If the product is charged when it is working, it will run the self-protection process to stop working automatically.)
4.The main part of the product has built-in rechargeable battery.
5.Please stop using it when the product indicates you the battery is low through voice prompt. Use it after recharging.

Multiple ways of charging the product

The way of charging	Through USB port on the computer
	Through mobile power supply
	Through standard charger plug (recommended)

Service time

The default time of usage is 10 minutes after running the product. For longer time of usage, please open the product again.

Directions for use

Long press on the ON/OFF for 3 seconds to open the product. The default pattern is auto mode;In the state of power-on,click on ON/OFF to switch modes automatically.There are 3 modes;In the state of power-on,double click on ON/OFF to pause the music or double click on ON/OFF again to replay the music; In the state of power-on, long press on the ON/OFF for 3 seconds to close the product.

One key manipulation of modes

AUTO mode：pressure + warm heat + music
↓
Dynamic mode：pressure + music
↓
sleep mode：warm heat + music

Troubleshooting

If there are any problems in the operation, please check the following parts. If the trouble is eliminated, the product is still unable to operate. Please turn off the power and contact the service center of the product for repairment.

Common faults and Solutions

Faults	Possible cause of failure	Solutions
Unable to boot	Low battery	Fully charged
	Mainframe protection (electricity)	Connected to the charger to allow the mainframe to automatically remove the protection（5seconds）
	The battery is not charged into electricity	Charger damage
The atmospheric pressure is too weak	Low electricity	Charge

Maintenance

►If the body is dirty, please wipe it with dry soft cloth
►If the body is especially dirty, the soft cloth can be soaked with medical alcohol to wipe the fuselage
►After using, the product should be placed in a safe place. Do not put it on the instrument.
►Measures should be taken to prevent moisture, prevent mice and prevent pollution.
►When it occurs some problems, a professional technician should be asked to repair it, and do not disassemble the instrument at will.

URBANWORX

SUPPORT info@ayonz.com / **DISTRIBUTOR** Ayonz Pty Ltd

Charging voltage	**DCSV 1A**
Charging current	**<2A**
Dimension	**95(w) x 77(d) x 235(h) mm**
NET Weight	**280g**
GROSS Weight	**286g**