

BACK

FRONT

1

2



**SUPPORT**  
info@ayonz.com  
1300 296 699



**SUPPORT**  
info@ayonz.com  
1300 296 699

# INSTRUCTION MANUAL

UX Libra 3

### General Safety

Read this manual thoroughly before you start using the scale.

Store this manual, the completed warranty card, your receipt and the product packaging. The safety precautions instructions reduces the risk of fire and injury when correctly complied to.

Please follow all instructions and take notice of all warnings.

#### To reduce the risk of injury:

- Keep batteries out of reach of children.
- Do not allow metal objects to touch or pierce the battery in the device.
- Do not expose batteries to excessive heat and direct sunlight.
- Never jump or stomp on the scale.
- Do not try to disassemble the scale.
- Handle with care and avoid dropping the scale while moving to prevent from accidentally damaging the scale.

### Caution

1. To ensure accuracy, it is recommended measure your weight at the same time every night or morning.
2. Please make sure new batteries are inserted when "LO" appears on the LCD screen which indicates batteries are out of power.
3. "Err" shows on LCD then indicates overload or error in taking weight measurement.

### Maintenance

1. Please make sure to take shoes off before standing on the scale to measure your weight.
2. The glass platform may be slippery when wet, make sure both your feet and scale glass is dry before using.
3. Use soft tissue with alcohol or glass cleaner to clean the surface of the scale if dirty. No soap or other chemicals. Keep away from water, heat and extreme coldness.

### HOW TO USE

#### STEP 1

Take the insulating strip out of the battery compartment. Place the scale on a hard flat surface.

#### STEP 2

Step on the scale gently and position your feet evenly near the centre and keep your body still until the scale stabilizes your weight.

The scale will auto shut off within seconds if its no longer in use.

### WARNING

**The product requires button batteries to operate and that these are hazardous to young children.**

#### WARNING - KEEP BATTERIES OUT OF REACH OF CHILDREN

- o Swallowing may lead to serious injury in as little as 2 hours or death, due to chemical burns and potential perforation of the oesophagus.
- o If you suspect your child has swallowed or inserted a button battery immediately call the 24-hour Poisons Information Centre on 13 11 26 for fast, expert advice.
- o Examine devices and make sure the battery compartment is correctly secured, e.g. that the screw or other mechanical fastener is tightened. Do not use if compartment is not secure.
- o Dispose of used button batteries immediately and safely. Flat batteries can still be dangerous.
- o Tell others about the risk associated with button batteries and how to keep their children safe.